


2011 **370Z**

QUICK REFERENCE GUIDE





- | | | | |
|---|--|--|---|
| 01 ENTER / NEXT SWITCHES* | 06 PADDLE SHIFTER* | 10 CRUISE CONTROL | 15 FRONT PASSENGER AIR BAG STATUS LIGHT* |
| 02 INSTRUMENT BRIGHTNESS CONTROL* | 07 WINDSHIELD WIPER / WASHER SWITCH | 11 INTELLIGENT KEY PORT* | 16 AUDIO SYSTEM |
| 03 VEHICLE INFORMATION DISPLAY* | 08 VEHICLE DYNAMIC CONTROL (VDC) OFF SWITCH* | 12 HOOD RELEASE* | 17 AUTOMATIC CLIMATE CONTROLS |
| 04 LOW TIRE PRESSURE WARNING LIGHT | 09 STEERING WHEEL SWITCHES FOR AUDIO / BLUETOOTH* | 13 TILT STEERING COLUMN ADJUSTMENT* | 18 SYNCHROREV™ MATCH MODE (S-MODE) SWITCH* |
| 05 HEADLIGHT AND TURN SIGNAL CONTROL | | 14 CONTROL PANEL DISPLAY | |

*See your Owner's Manual for more information.

NEW SYSTEM FEATURES

Opening the Soft Top (Roadster models)	2
--	---

ESSENTIAL INFORMATION

Loose Fuel Cap	3
Tire Pressure Monitoring System (TPMS)	3
Automatic Power Windows	4

FIRST DRIVE FEATURES

NISSAN Intelligent Key™ System	5
Power Seat Adjustments (if so equipped)	5
Outside Mirror Control Switch	6
Starting/Stopping the Engine	6
Headlight Control Switch	7
Windshield Wiper Switch	7
Automatic Climate Controls	8
FM/AM/XM® Radio with CD/DVD Player (if so equipped)	9
Parking Brake	9
Rear Hatch / Trunk Lid Release	9
Soft Top Operation (Roadster models)	10
Fuel-Filler Door	10

SYSTEM GUIDE

Cruise Control	11
Bluetooth® Hands-free Phone System (if so equipped)	11
Navigation System (if so equipped)	11
DVD Entertainment System (if so equipped)	12
HomeLink® Universal Transceiver (if so equipped)	12



- Always wear your seat belt.
- Supplemental air bags do not replace proper seat belt usage.
- Children 12 and under should always ride in the rear seat properly secured in child restraints or seat belts according to their age and weight.
- Do not drink and drive.

For more information, refer to the **“Safety -- Seats, seat belts and supplemental restraint system (section 1)”** of your Owner’s Manual.



Additional information about your vehicle is also available in your Owner’s Manual, Navigation System Owner’s Manual, Electronic Quick Reference Guide (EQRG) and at www.nissanusa.com.



This easy-to-use Quick Reference Guide is intended to help you more fully appreciate some of the unique features and functions of your new vehicle. However, it is not intended to replace your Owner’s Manual. The Owner’s Manual contains more detailed information to help you better understand the important safety warnings, features, operation and maintenance of your vehicle. All information, specifications, photographs and illustrations in this publication are those in effect at the time of printing. NISSAN reserves the right to change specifications or design without notice and without obligation.

new system features

OPENING THE SOFT TOP (Roadster models)

- The soft top can be opened from outside the vehicle using the door handle request switch **01** as follows:
 - The ignition switch must be in the **OFF** position.
 - Push and hold the door handle request switch **01** until the soft top is fully opened.

NOTE: It is important to make sure the NISSAN Intelligent Key™ is with you (that is, in your pocket or purse).


For more information, refer to the "**Pre-driving checks and adjustments (section 3)**" of your Owner's Manual.



LOOSE FUEL CAP

- A LOOSE FUEL CAP warning message will appear in the vehicle information display **01** when the fuel-filler cap is not tightened correctly.
- The warning message will disappear when the vehicle detects the fuel-filler cap is properly tightened and the reset button **02** is pressed.
- If the cap is not properly tightened the Malfunction Indicator Light SERVICE ENGINE SOON may illuminate.


For more information, refer to the “**Instruments and controls (section 2)**” and the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.



TIRE PRESSURE MONITORING SYSTEM (TPMS)


- A CHECK TIRE PRESSURE warning message will appear in the vehicle information display **01** and the TPMS light will illuminate when one or more tires are low on pressure and air is needed.
- After tire pressures are adjusted, drive the vehicle at speeds above 16 MPH (25km/h) and the warning and indicator light will disappear.
- When the low tire pressure warning light flashes for approximately 1 minute and then remains on, the TPMS is not functioning properly. Have the system checked by a NISSAN dealer.
- Tire pressure rises and falls depending on the heat caused by the vehicle’s operation and the outside temperature. Low outside temperature can lower the temperature of the air inside the tire, which can cause a lower tire inflation pressure. This may cause the low tire pressure warning light to illuminate. If the warning light illuminates in low ambient temperature, check the tire pressure in all four tires.

For more information, refer to the “**Instruments and controls (section 2)**” and the “**Starting and driving (section 5)**” of your Owner’s Manual.



AUTOMATIC POWER WINDOWS

- Your power windows have an automatic adjusting function to ensure windows close completely to help seal against wind noise and weather leaks.
- When the front doors are opened, the windows automatically lower slightly to avoid contact between the windows and the side roof panels.
- If your vehicle's battery has been discharged or disconnected, your power window automatic function will not operate.
- Refer to your Owner's Manual for information to initialize your power window system.
- If the power window functions do not operate properly after initializing the system, have your vehicle checked by a NISSAN dealer.



For more information, refer to the "**Instruments and controls (section 2)**" of your Owner's Manual.

NISSAN INTELLIGENT KEY™ SYSTEM

The NISSAN Intelligent Key™ System allows you to lock or unlock your vehicle, open your rear hatch/trunk lid and start the engine.

- To lock or unlock the driver's or front passenger's door, push the corresponding door handle request switch **01** once.
- Push the door handle request switch **01** within 60 seconds of unlocking the door and all other doors will unlock.


NOTE: It is important to make sure the Intelligent Key is with you (that is, in your pocket or purse).

For more information, refer to the "Pre-driving checks and adjustments (section 3)" of your Owner's Manual.



POWER SEAT ADJUSTMENTS (if so equipped)

- Push the control switch **01** forward or backward to slide the seat forward or backward.
- Push the switch **02** forward or backward to adjust the angle of the seatback.



MANUAL SEAT LIFTER (if so equipped for driver's seat)

- Turn either dial to adjust the angle and height of the seat cushion to the desired position.



MANUAL LUMBAR SUPPORT
(if so equipped for driver's seat)

- Your driver's seat lumbar support is located on the inboard side of the driver's seat. Adjust it by moving the lever up or down.



For more information, refer to the "Safety — Seats, seat belts and supplemental restraint system (section 1)" of your Owner's Manual.

first drive features

OUTSIDE MIRROR CONTROL SWITCH

- Turn the control switch right or left to select the right or left side mirror.
- Move the control switch up, down, right or left to adjust the mirror angle.

For more information, refer to the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.



STARTING/STOPPING THE ENGINE

AUTOMATIC TRANSMISSION (if so equipped)

- Depress the brake pedal.
- Move the shift lever to **P (PARK)**.
- Push the ignition switch to start the engine.

NOTE: It is important to make sure the NISSAN Intelligent Key™ is with you (that is, in your pocket or purse).

MANUAL TRANSMISSION (if so equipped)

- Depress the brake pedal.
- Move the shift lever to **N (NEUTRAL)**.
- Depress the clutch pedal to the floor.
- Push the ignition switch to start the engine.



TURNING THE ENGINE OFF

- For an automatic transmission, move the shift lever to the **P (PARK)** position, apply the parking brake and push the ignition switch.
- For a manual transmission, move the shift lever to the **N (NEUTRAL)** position, apply the parking brake and push the ignition switch.



EMERGENCY ENGINE SHUT OFF

To shut off the engine in an emergency situation while driving, perform one of the following procedures:


- Rapidly push the push button ignition switch 3 consecutive times, or
- Push and hold the push button ignition switch for more than 2 seconds.

For more information, refer to the “**Starting and driving (section 5)**” of your Owner’s Manual.

HEADLIGHT CONTROL SWITCH

- Turn the headlight control switch **01** to the  position to turn on the front parking, side marker, tail, license plate and instrument panel lights.
- Turn the switch **01** to the  position to turn on the headlights.


For more information, refer to the “**Instruments and controls (section 2)**” of your Owner’s Manual.



WINDSHIELD WIPER SWITCH

Move the lever to the following positions to operate the windshield wipers:

- 01** Mist (**MIST**) - One sweep operation of the wipers.
- 02** Intermittent (**INT**) – Wipers operate intermittently.
- 03** Low (**LO**) - Wipers operate at a continuous low-speed.
- 04** High (**HI**) - Wipers operate at a continuous high-speed.



For more information, refer to the “**Instruments and controls (section 2)**” of your Owner’s Manual.

first drive features



AUTOMATIC CLIMATE CONTROLS


01 FAN SPEED CONTROL DIAL

- Turn the dial to the left to decrease fan speed or to the right to increase fan speed.


02 AUTO BUTTON/TEMPERATURE CONTROL DIAL

- Press the **AUTO** button to turn the system on and the fan speed, air flow distribution and temperature will be automatically maintained. Turn the temperature control dial left for cooler or right for warmer air.

03 DEFROSTING/DEFOGGING FRONT AND SIDE WINDOWS

- Press the front defroster button  to turn the system on or off.

04 DEFROSTING REAR WINDOW AND OUTSIDE MIRRORS (if so equipped)

- Push the rear window defroster switch  to turn the system on or off.

For more information, refer to the “**Instruments and controls (section 2)**” and the “**Center display, heater, air conditioner, audio, phone and voice recognition systems (section 4)**” of your Owner’s Manual.



FM/AM/XM[®]* RADIO WITH CD/DVD PLAYER (if so equipped)

01 VOLUME/ON-OFF CONTROL KNOB

- Press the **VOLUME/ON-OFF** knob to turn the system on or off.
- Turn the **VOLUME/ON-OFF** knob right or left to increase or decrease the volume.

02 TUNE/FOLDER/AUDIO CONTROL KNOB

- To manually tune the radio, turn the **TUNE/FOLDER** knob left or right.

*XM[®] Satellite Radio is only available on vehicles equipped with optional XM[®] satellite subscription service.

For more information, refer to the “**Center display, heater, air conditioner, audio, phone and voice recognition systems (section 4)**” of your Owner’s Manual.

PARKING BRAKE

- To apply, pull the parking brake lever **01** up.
- To release, firmly press the foot brake while slightly pulling up on the parking brake lever. Press the button **02** and lower the lever completely.

For more information, refer to the “**Starting and driving (section 5)**” of your Owner’s Manual.




REAR HATCH/TRUNK LID RELEASE

- Unlock the rear hatch/trunk lid by pushing the request switch **01**.
- Once unlocked, push the opener switch **02** and pull up to open the rear hatch/trunk lid.

NOTE: It is important to make sure the NISSAN Intelligent Key™ is with you (that is, in your pocket or purse).

For more information, refer to the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.



first drive features


SOFT TOP OPERATION (Roadster models)

Before opening or closing your soft top, refer to the Owner's Manual for detailed warnings and cautions regarding soft top operation.

Soft Top Operation



1. Make sure the area is clear of obstructions and that there is at least 6 feet of clearance above the vehicle.
2. Apply the parking brake and move the shift lever to the **P (PARK)** position (automatic transmission) or the **N (NEUTRAL)** position (manual transmission).
3. Depress the brake pedal.
4. Start the engine.
5. Push and hold the soft top operating switch, located on the center console, to **OPEN** **01** or **CLOSE** **02** until the top is fully opened or closed.

For more information, refer to the "**Pre-driving checks and adjustments (section 3)**" of your Owner's Manual.



FUEL-FILLER DOOR

Open the fuel-filler door using one of the following operations, then push and release the left side of the door.

- Push the door handle request switch while carrying the NISSAN Intelligent Key™ with you.
- Press the  button on the Intelligent Key.
- Push the power door lock switch to the  position.

For more information, refer to the "**Pre-driving checks and adjustments (section 3)**" of your Owner's Manual.



CRUISE CONTROL

- The cruise control system enables you to set a constant cruising speed.
- The system will automatically maintain the set speed until you tap the brake pedal, accelerate, cancel or turn the system off.

For more information, refer to the **“Starting and driving (section 5)”** of your Owner’s Manual.



BLUETOOTH® HANDS-FREE PHONE SYSTEM (if so equipped)

- With an overhead microphone and sound transmitted through the audio system speakers, the Bluetooth® Hands-free Phone System utilizes Bluetooth wireless technology and voice recognition to provide hands-free cellular phone communication.

For more information, refer to the **“Center display, heater, air conditioner, audio, phone and voice recognition systems (section 4)”** of your Owner’s Manual or please visit www.nissanusa.com/bluetooth.



NAVIGATION SYSTEM (if so equipped)

- Your Navigation System can calculate a route from the current location to a preferred destination. The real-time map display and turn-by-turn voice guidance will lead you along the route.
- The Navigation System will continually update your vehicle’s position. If you have deviated from the original route, it will recalculate the route from your current location.
- The Navigation System can also provide you with important data, such as; distance to empty, your tire rotation schedule and other maintenance interval reminders.

For more information, refer to your Navigation System Owner’s Manual.

DVD ENTERTAINMENT SYSTEM (if so equipped)

- With this Entertainment System, you can play video files via a DVD or CD from the control panel.
- You can also operate auxiliary devices such as; video games, camcorders or portable video players through the auxiliary jacks.
- To view movies on the control panel, stop the vehicle in a safe location, move the shift lever to the **P (PARK)** position and apply the parking brake.
- To reduce driver distraction, movies will not be shown on the front display while the vehicle is in any drive position.

For more information, refer to the “**Center display, heater, air conditioner, audio, phone and voice recognition systems (section 4)**” of your Owner’s Manual.



HOMELINK® UNIVERSAL TRANSCEIVER (if so equipped)

- The HomeLink® system can learn and consolidate the functions of up to three different hand-held transmitters, operating items such as; garage doors, property gates, outdoor and indoor lights or alarm systems.

For more information, refer to the “**Instruments and controls (section 2)**” of your Owner’s Manual, the HomeLink® website at www.homelink.com or call 1-800-355-3515.



Nissan, the Nissan Brand Symbol, "SHIFT_" tagline,
Z and Nissan model names are Nissan trademarks.
© 2010 Nissan North America, Inc.
QR1E 0Z34U0
Printing: September 2010 (04)

