


Operation Guide ANALOG (HK-W) CASIO®

• Your watch may differ somewhat from the one shown in the illustration.

[Modules 1362, 1398, 1770, 2799, 3378, 4370]

To set the time
Pull out the crown. Set the hands by rotating the crown. Push the crown back in on a time signal to resume timekeeping.




Crown

[Modules 705, 706, 1300, 1311, 1330, 1344, 1360, 1399, 1747, 1771, 4394, 5049] [Modules 1782, 4328, 4747]

To set the time

- When the second hand is at 12 o'clock, pull out the crown to stop it.
- Set the hands by rotating the crown. Move the minute hand four or five minutes past the setting you want, and then back them up to the setting.
- Push the crown back in on a time signal to resume timekeeping.




Crown

[Modules 707, 708, 1331, 1332, 1342, 1345, 1346, 1787, 2717, 2718, 2719, 2725, 2731, 2748, 2749, 2783, 2784, 3363, 3711, 3712, 4393, 5025, 5044]

To set the time

- When the second hand is at 12 o'clock, pull out the crown to the second click to stop it.
- Set the hands by rotating the crown. Move the minute hand four or five minutes past the setting you want, and then back them up to the setting.
- Push the crown back in on a time signal to resume timekeeping.




Crown (Normal position)
First click (Day setting)
Second click (Time setting)

To set the day

• Avoid setting the day between 8:00 p.m. and 2:00 a.m. The day may not change in the following day if you do.

- Pull out the crown to the first click.
- Set the day by rotating the crown.
- Push the crown back in to its normal position.




Crown (Normal position)
First click (Day setting)

[Modules 709, 1333, 1347, 3716]

To set the time

- When the second hand is at 12 o'clock, pull out the crown to the second click to stop it.
- Set the hands by rotating the crown. Move the minute hand four or five minutes past the setting you want, and then back them up to the setting.
- Push the crown back in on a time signal to resume timekeeping.



Crown (Normal position)
First click (Day, day of week setting)
Second click (Time setting)


To set the day and day of the week

• Avoid setting the day and day of the week between 8:00 p.m. and 4:00 a.m. The day and day of the week may not change in the following day if you do.

- Pull out the crown to the first click.
- Set the day by rotating the crown counterclockwise.
- Set the day of the week by rotating the crown clockwise. Confirm that the correct language (English or Spanish) is selected.
- Push the crown back in to its normal position.

[Days of the Week]	
English	Spanish
SUN	DOM
MON	LUN
TUE	MAR
WED	MIER
THU	JUEV
FRI	VIER
SAT	SAB

■ For watch with the elapsed time bezel
Rotate the elapsed time bezel to align the ▽ mark with the minute hand.
After certain amount of time elapsed, read the graduation on the elapsed time bezel which the minute hand points to.
The elapsed time is indicated.



Elapsed time bezel

- Some water resistant models are equipped with a screw lock crown.
- With such models, you must unscrew the crown in the direction noted in the illustration to loosen it before you can pull it out. Do not pull too forcibly on such crowns.
- Also note that such watches are not water resistant while their crowns are loosened. Be sure to screw the crowns back in as far as they will go after making any setting.

