


Diplomat®

Operation Manual

ITEM NO.: #31-400-01
 ITEM NO.: #31-400-10
 ITEM NO.: #31-566

- Thank you for purchasing this great product.
- Please take a few moments to read through the manual to ensure proper operation.
- Please keep the instruction manual for further reference.

the switch and adaptor port can be found on the rear of the unit.



Item Specification

Power	Input:AC/100-240V,50-60Hz ; Output:DC/4V 500mA
Feature	1.wind clockwise or anticlockwise by operating the switch 2.Count down Function:Auto rotate 1 hour & rest for 3 hours 3.TPD:2160 turns per day.
Size	128x140x156mm (L*W*H)
Weight	About 400g

Note:

- * Please use the AC adapter
 Input:AC/100-240V,50-60Hz
 Output:DC/4V 500mA supplied with the unit.
- * Remove the adapter when the winder is not in use.
- * Always turn off the power when inserting or removing watches.
- * Don't shake or rotate when winder is stationary.






1. Insert the adaptor into the adaptor port and insert the plug it into the electrical outlet.
2. Turn the switch [ON].
 - * Position the product as show in the picture.
 - * Slide the switch up, the winder will turn clockwise.
 - * Slide the switch down, the winder will turn counter-clockwise.
 - * The center position turns the unit off.

Attention:

- * When inserting and removing the wrist watch, please ensure the electrical power is off, as it may cause malfunction.

For warranty information or to report a problem with your winder, please contact the manufacturer at: Diplomatwinders@gmail.com

Instructions for placing the watch on the winder

<p>Step 1 : Open the cover, then use your index finger and thumb to hold the watch winder from the two sides marked with two arrows. With some force, pull out the watch holder. There may be a large watch adapter on top. If that is the case, remove it first, then pull out the holder.</p>		
<p>Step 2 : Place the watch around the holder by pushing in the spring in the back of the holder, then placing your watch around the holder, then let go of the spring</p>		
<p>Step 3 : Once the watch is on the holder, place the holder back into the winder. Push until you hear a click signifying that it is securely in the winder.</p>		
<p>Step 4 : Turn on the winder to the desired setting.</p>		

The following are the turns per day (TPD) which each setting is programmed to run at:

Model # 31-400 and 31-566: 2160 TPD

Model #'s 31-401, 31-497, 31-567, 31-568 and 31-569

Mode A: 342 TPD Mode B: 864 TPD

Mode C: 1080 TPD Mode D: 2160 TPD

Model #'s 31-408

Mode A: 1440 TPD Mode B: 1440 TPD

Mode C: 5670 TPD Mode D: 2152 TPD

Put the additional watch holder case onto the watch holder for the larger size wristwatch. The additional watch holder case is including in the package.

